

## EF 99L/12,5 K M Cat. 2024 Garden tractor



### Документы

Mulching Kit

---

Mowing deck

---

Engine

---

Tank

---

Transmission

---

Frame

---

Front axle

---

Steering arm

---

Rear axle

---

Seat

---

Cutting plate lifting

---

Electrical parts

---

body

---

Towing hitch

---

Labels

---

Top cover

---

Ignition system

---

Flywheel

---

Starter lever

---

Control lever

---

Carburetor

---

Air filter

---

Valves

---

Crankshaft and piston


---

Crankcase cover

---

Cylinder and crankcase


---



## изображение Mulching Kit


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
3	2	TS000043R	Hook				
4	2	TS000044R	Tie rod				
6	1	TS000046R	Deflector				




## изображение Mowing deck

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000115R	Right guard				
4	5	TS000066R	Clamp				
7	1	TS000116R	Pin				
8	1	TS000117R	Spring				
9	2	TS000071R	Screw				
10	2	TS000074R	Wheel				
12	1	TS000118R	Mount				
14	1	TS000119R	Belt cover				
16	1	TS000120R	Bushing				
17	2	TS000104R	Water hose connection				
20	1	TS000121R	Lever				
21	1	TS000122R	Bushing				
22	1	TS000007R	Pulley				
24	1	TS000123R	Belt				
25	1	TS000124R	Bracket				
27	1	TS000125R	Guard sx				
28	1	TS000126R	Pulley				
29	1	TS000127R	Bushing				
32	1	TS000128R	Belt cover				
33	1	TS000129R	Spacer				
34	1	TS000130R	Spring				
35	1	TS000065R	Screw				
36	1	TS000131R	Mowing deck				
37	2	TS000132R	Nut				
38	2	TS000111R	Pulley				
39	2	TS000082R	Key				
40	2	TS000133R	Blade shaft				
41	2	TS000085R	Disc (guard)				
42	4	TS000086R	Thrust bearing				
43	2	TS000134R	Support				
45	2	TS000135R	Guard				
46	2	TS000099R	Key				
47	2	TS000095R	Blade hub				
48	1	TS000136R	Pin				
51	2	TS000091R	Plate				
53	2	TS000137R	Blade				
54	2	TS000097R	Washer				
56	2	TS000098R	Screw				
60	1	TS000138R	Pin				
61	1	TS000139R	Spring				
62	1	TS000140R	Locking lever				
63	1	TS000141R	Lever support				
64	1	TS000142R	Deflector				



## изображение Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000147R	Knob				
4	1	TS000008R	Throttle cable				
7	1	TS000009R	Key				
8	1	TS000148R	Pulley			Motore 12,5 KM - Engine	
8	1	TS000159R	Pulley			Motore 14,5 K / 16 K - Engine 14,5 K / 16 K	
9	1	TS000010R	Support				
11	1	TS000149R	Clutch				
12	1	TS000150R	Bushing				
13	1	TS000151R	Thickness				
14	1	TS000152R	Bolt				
15	1	TS000153R	Plate				
17	1	TS000154R	Bracket			Motore 12,5 KM - Engine	
17	1	TS000160R	Bracket			Motore 14,5 K / 16 K - Engine 14,5 K / 16 K	
19	1	TS000155R	Exhaust pipe				
23	1	TS000156R	Gasket				
24	1	TS000157R	Muffler				
25	1	TS000158R	Support				
29	1	TS000011R	Grid				






## изображение Tank


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
10	1	TS000012R	Filter				
11	1	TS000161R	Tank				
13	1	TS000162R	Band				
14	1	TS000163R	Fuel hose				
15	1	TS000164R	Band				
16	1	TS000013R	Tank cap				




## изображение Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000252R	Pin				
2	1	TS000253R	Spacer				
5	1	TS000254R	Guide pulley				
6	2	TS000173R	Bushing				
9	1	TS000255R	Support				
12	1	TS000122R	Bushing				
14	1	TS000256R	Rod				
15	1	TS000007R	Pulley				
17	1	TS000130R	Spring				
20	1	TS000257R	Slide				
21	1	TS000258R	Spacer				
24	1	TS000259R	Screw				
26	3	TS000023R	Pulley				
27	1	TS000006R	Pulley				
28	1	TS000005R	Thrust bearing				
30	1	TS000024R	Belt				
31	2	TS000260R	Bushing				
32	1	TS000261R	Guide belt				
33	1	TS000262R	Guide belt				




## изображение Frame

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000165R	Right footboard support				
4	1	TS000166R	Footrest pad			Destra; Right	
5	1	TS000167R	Right footboard cover				
8	1	TS000168R	Right footboard support			Sinistra; Left	
10	2	TS000169R	Bushing				
12	1	TS000170R	Frame				
13	1	TS000171R	Hood support			Sinistra; Left	
14	1	TS000172R	Support				
15	4	TS000014R	Washer				
16	1	TS000015R	Bumper				
17	4	TS000173R	Bushing			Destra; Right	
18	1	TS000016R	Bumper				
19	1	TS000017R	Lower hood				
22	1	TS000174R	Hood support				
23	1	TS000175R	Support				
25	2	TS000176R	Plate				
26	1	TS000177R	Column support				
28	1	TS000178R	Left footboard support				
29	1	TS000179R	Footrest pad				
30	1	TS000180R	Left footboard cover				
31	1	TS000181R	Frame				
32	2	TS000182R	Support				
33	1	TS000183R	Left footboard support				



## изображение Front axle


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	TS000198R	Hub cap				
3	2	TS000199R	Washer				
4	4	TS000200R	Spacer				
5	2	TS000018R	Compl. front wheel				
5,4	4	TS000204R	Thrust bearing				
6	1	TS000019R	Pin			Destro; Right	
8	4	TS000020R	Bushing				
9	1	TS000205R	Front axle				
11	1	TS000021R	Lever				
12	2	TS000083R	Washer				
17	1	TS000206R	Spacer				
18	2	TS000068R	Nipple				
21	1	TS000022R	Pin			Sinistro; Left	






## изображение Steering arm

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000267R	Joint				
3	1	TS000268R	Tie rod				
5	1	TS000269R	Plate				
8	1	TS000270R	Sleeve				
9	1	TS000271R	Bushing				
10	1	TS000272R	Snap ring				
11	1	TS000273R	Steering arm				
13	2	TS000274R	Bushing				
14	1	TS000275R	Tie rod				
16	1	TS000026R	Sprocket				
17	1	TS000276R	Pin				
19	1	TS000378R	Bushing				
20	1	TS000277R	Bushing				
21	1	TS000278R	Cotter pin				
22	1	TS000279R	Fixing plate				
23	2	TS000280R	Bushing				
24	1	TS000027R	Sector				
25	1	TS000281R	Fixing plate				
26	1	TS000282R	Joint				
28	1	TS000283R	Spacer				
30	1	TS000284R	Steering wheel				
31	1	TS000028R	Support				
32	1	TS000379R	Washer				
33	1	TS000375R	Cover			Rosso - Red	




## изображение Rear axle

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	TS000198R	Hub cap				
2	2	TS000207R	Snap ring				
3	4	TS000199R	Washer				
4	2	TS000212R	Compl. rear wheel				
5	2	TS000210R	Key				
6	1	TS000211R	Transmission				
7	1	TS000213R	Support				
13	1	TS000214R	Brake rod				
14	1	TS000215R	Snap ring				
15	1	TS000216R	Pulley				
16	1	TS000217R	Control rod				
20	1	TS000218R	Gearbox lever				
23	1	TS000219R	Gearbox lever				
24	1	TS000220R	Pin (lever)				
28	2	TS000221R	Spacer				
29	1	TS000222R	Joint				
30	1	TS000223R	Snap ring				
31	1	TS000224R	Spring				
32	1	TS000225R	Gearbox lever				
33	1	TS000226R	Knob				
34	1	TS000227R	Joint				
35	1	TS000228R	Plate				
36	1	TS000229R	Spring				
38	1	TS000230R	Support				
39	2	TS000231R	Support				
43	1	TS000232R	Bushing				
44	1	TS000233R	Compl.brake lever				
46	1	TS000234R	Control rod				
47	1	TS000235R	Handle				
48	1	TS000236R	Fork				
49	1	TS000237R	Spring				
50	1	TS000238R	Brake pedal				
51	1	TS000239R	Cover moulding				




## изображение Seat

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000285R	Bar				
4	2	TS000286R	Spring				
7	2	TS000287R	Cover				
8	1	TS000288R	Seat support				
9	2	TS000289R	Screw				
10	2	TS000290R	Slide				
12	1	TS000029R	Seat switch				
13	1	TS000372R	Seat			Rosso - Red	
14	4	TS000291R	Spacer				



## изображение Cutting plate lifting


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
3	2	TS000292R	Rod				
4	1	TS000293R	Tie rod				
6	1	TS000294R	Joint				
10	1	TS000308R	Rod				
11	1	TS000309R	Axel lift				
12	1	TS000297R	Rod				
13	1	TS000298R	Support				
15	4	TS000231R	Support				
16	3	TS000299R	Joint				
17	1	TS000310R	Lever				
19	1	TS000301R	Plate				
20	1	TS000226R	Knob				
21	1	TS000030R	Support				
22	1	TS000302R	Spring				
25	1	TS000303R	Spring				
26	1	TS000031R	Lever				
27	1	TS000223R	Snap ring				
28	2	TS000378R	Bushing				
29	1	TS000304R	Lever				
30	1	TS000311R	Tie rod				
31	1	TS000312R	Tie rod				






## изображение Electrical parts

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000314R	Battery cables				
2	1	TS000334R	Wiring				
3	20	TS000316R	Band				
3	5	TS000317R	Band				
4	1	TS000318R	Switch protection				
5	1	TS000032R	Switch				
6	1	TS000319R	Battery cables				
8	1	TS000033R	Solenoid				
11	1	TS000323R	Clamp				
13	1	TS000324R	Wire				
14	1	TS000325R	Fuse				
15	1	TS000034R	Switch				
16	1	TS000326R	Switch				
17	1	TS000035R	Shoe				
19	1	TS000037R	Micro-switch				
20	1	TS000332R	Belt				
21	1	TS000038R	Battery				
22	2	TS000333R	Bracket				



изображение body


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000340R	Wiring				
2	1	TS000341R	Adapter				
3	1	TS000342R	Deflector				
4	1	TS000343R	Right guard				
6	5	TS000344R	Fairled				
7	1	TS000360R	Right guard			Rosso - Red	
10	2	TS000345R	Pin				
11	1	TS000346R	Headlamp				
12	1	TS000363R	Guard				
13	1	TS000039R	Upper hood				
14	1	TS000347R	Headlamp				
15	1	TS000366R	Engine cover			Rosso - Red	
16	1	TS000369R	Left guard			Rosso - Red	
17	1	TS000348R	Left guard				
19	1	TS000349R	Cover				
20	4	TS000350R	Shock absorber				
22	1	TS000351R	Dashboard				
23	9	TS000066R	Clamp				
24	1	TS000352R	Panel				
25	1	TS000040R	Cover				
29	1	TS000042R	Cover				
30	1	TS000356R	Guard				
31	2	TS000173R	Bushing				



## изображение Towing hitch

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000358R	Towing hitch				
3	2	TS000359R	Spacer				



## изображение Labels

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000405R	Label				
2	1	TS000396R	Label				
3	1	TS000387R	Label			99L/12,5KM	






## изображение Top cover

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150654	Pin				
2	2	L66150822	Stud				
3	1	3055122R	Spark plug				
4	4	L66150818	Bolt				
5	1	L66151483	Set cover				
6	1	L66150750	Cover				
7	1	L66150393	Screw				
8	1	L66151179	Gasket set				
9	1	L66151180	Head comp.cylinder				



## изображение Ignition system


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150771	Fan				
2	1	L66150802	Pulley				
3	1	L66150823	Nut				
4	1	L66150803	Cover				
5	1	L66150775	Cover				
6	1	L66150818	Bolt				
7	1	L66150774	Guard				
8	1	L66150464	Screw				
9	3	L66150393	Screw				



## изображение Flywheel


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151485	Rectifier				
2	2	L66150464	Screw				
3	1	L66151486	Grip-end				
4	1	L66151487	Plate				
5	4	L66150816	Bolt				
6	1	L66150804	Flywheel				
7	2	L66150817	Bolt				
8	1	L66151495	Engine stop wire				
9	1	L66150810	Spark plug cap				
10	1	L66151488	Ignition coil				
11	1	L66151489	Clip				



## изображение Starter lever

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151490	Starter lever				
2	1	L66150808	Bracket				
3	2	L66150821	Bolt				





## изображение Control lever





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150251	Screw				
2	1	L66151491	Control				
3	2	L66150393	Screw				
4	1	L66150792	Spring				
5	1	004400959R	Nut				
6	1	L66150793	Governor arm shaft				
7	1	L66150382	Screw				
8	1	L66150791	Governor rod				
9	1	L66150790	Starter cable				
10	1	L66150813	Bolt				
11	1	L66150789	Plate				
12	1	L66150795	Throttle rod				



## изображение Carburetor

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151183	Carburetor				
2	1	L66150956	Gasket				
3	1	L66150464	Screw				
4	1	L66150788	Insulator				
5	2	L66150749	Tube				
6	1	L66151492	Fuel hose				
7	1	L66151503	Fuel hose				
8	1	L66151179	Gasket set				



## изображение Air filter


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150786	Filter				
2	1	L66150799	Filter				
3	2	L66150801	Bolt				
4	1	L66150798	Filter kit				
5	1	L66150453	Screw				
6	2	004400959R	Nut				
7	1	L66151184	Muffler assy				
8	1	L66150800	Gasket				
9	2	L66151185	Screw				

12●



## изображение Valves

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150782	Suction/exhaust valve kit				
2	2	L66150560	Slide				
3	2	L66150561	Seal ring				
4	2	L66150559	Spring				
5	2	L66150558	Clamp				
6	4	L66150557	Valve				
7	2	L66150763	Compensator				
8	1	L66150766	Plate				
9	2	L66150764	Equalizer rod				
10	2	L66150554	Slide				
11	1	L66150762	Camshaft assy				
12	1	L66151180	Head comp.cylinder				






## изображение Crankshaft and piston

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151186	Piston ring set				
2	2	L66150669	Ring				
3	1	L66151182	Piston assy				
4	1	L66150693	Piston pin				
5	1	L66150758	Connecting rod cpl.				
6	2	L66150759	Bolt				
7	1	L66150760	Crankshaft				
8	1	L66150964	Compensator				
9	2	L66150825	Washer				
10	1	L66150963	Compensator				


9 \*



## изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	L66150251	Screw				
2	1	L66150768	Oil pump cover				
3	1	L66150756	Seal ring				
4	1	L66150767	Oil pump				
5	1	L66150830	Oil seal				
6	10	L66150820	Bolt				
7	2	L66150828	Pin				
8	1	L66150772	Deflector				
9	1	L66151179	Gasket set				
10	1	L66150662	Governor				
11	1	L66150769	Oil filter				
12	1	L66150752	Plate				
13	1	L66150770	Filter cover				
14	1	L66150817	Bolt				
15	1	L66151493	Cover				
16	1	L66150743	Close nipple				
17	1	L66150740	Oil cap assy				
18	1	L66150453	Screw				
19	1	L66150665	Bearing				

11 \*



## изображение Cylinder and crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151494	Breather fuel pipe				
2	1	L66150353	Goupille				
3	1	L66150660	Oil seal				
4	1	L66150824	Washer				
5	1	L66150794	Governor arm shaft				
6	1	L66150744	Gasket				
7	1	L66150665	Bearing				
8	1	L66150741	O-ring				
9	1	L66150410	Reed valve				
10	3	L66150464	Screw				
11	1	L66151179	Gasket set				
12	1	L66150745	Cover				
13	1	L66150829	Bearing				
14	2	L66150830	Oil seal				
15	1	L66150393	Screw				
16	1	L66150739	Valve				
17	1	L66151188	Crankcase				