

## LR 48 TK ALL ROAD PLUS 4 (K655) EURO 5 Lawnmower



### Документы

[Illustrated parts list](#)

---

[Crankcase](#)

---

[Crankcase cover](#)

---

[Shaft + piston](#)

---

[Reed valve kit](#)

---

[Ignition system](#)

---

[Carburetor](#)

---

[Air filter](#)

---

[Control lever](#)


---

[Muffler](#)

---

[Tank](#)

---



## изображение Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060398BR	Traction lever				
2	2	3918009R	Washer				
3	1	66060058CR	Traction cable				
4	1	66110845	Guard				
5	7	3914006R	Nut				
6	1	66070924R	Handle				
7	1	66030038	Grommet				
8	1	66070466R	Lock				
9	1	66070233A	Guard kit				
10	8	3035023R	Bearing				
11	1	66060421BR	Handlebar				
12	1	66070749	Axle kit				
13	2	66070944R	Tightening handle				
14	1	8202126R	Key				
15	2	66060231R	Band				
16	2	3910015R	Screw				
17	4	3914012R	Nut				
18	1	66070437R	Left sprocket				
19	1	66110753R	Shutter				
20	1	66072047R	Frame				
21	1	66070876R	Grassbag				
22	2	66070522R	Cover				
23	1	66110609A	Kit spring				
24	1	66110026R	Deflector axle				
25	1	66110762A	Deck				
26	2	3916015R	Washer				
27	2	66070885R	Wheel cover				
28	1	66030037R	Belt				
29	1	66071084R	Pulley				
30	1	3022020R	Plug				
31	1	66070035BR	Spring				
32	1	66070488R	Guard				
33	4	3024012R	Snap ring				
34	7	3916008R	Washer				
35	1	66110100	Rod				
36	1	66070436R	Right sprocket				
37	1	66070287AR	Rear axle				
38	3	3806076R	Screw				
39	1	66070017ER	Transmission				
40	5	011200035R	Screw				
41	1	66070286CR	Lever				
42	2	66070756	Wheel cover				
43	1	66030044	Spacer				
44	1	66070036R	Spring				


## изображение Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	2	66071056R	Complete wheel				
46	2	8202311R	Ring				
47	2	66070888R	Wheel cover				
48	1	66060010R	Roller				
49	1	66060316AR	Brake lever				
50	1	3906150R	Screw				
51	2	66060030R	Bushing				
52	1	66030276R	Engine break cable				
53	1	66060384R	Washer				
54	1	66030256R	Hub Ø22,2mm				
55	1	66110594R	Mulching blade				
56	1	66070905	Grassbag kit				
57	2	66030039	Plate				
58	4	3960031R	Screw				
59	6	3801022R	Screw				
60	2	66110781R	Support				
61	2	3045035R	Retainer washer				
62	2	3045034R	Retainer washer				
63	3	66070228AR	Support				
64	1	66070980R	Spring				
65	1	66070133R	Support				
66	2	66070722R	Complete wheel				
67	1	66070341AR	Throttle lever				
68	1	3910019	Screw				
69	2	3960072	Screw				
70	1	66070128R	Dashboard			sostituito da particolare	
71	1	66070384R	Throttle cable				
72	1	66110727	Labels kit			replaced by an	
73	1	66070291R	Sector				
74	1	3806049	Screw				
75	4	3035023R	Bearing				
76	1	8203374R	Spring				
77	2	3064037R	Washer				
78	1	66060425R	Handle kit				
79	2	66060381BR	Pin				
80	2	3024006R	Snap ring				
81	1	66110828R	Mulching cap				
82	1	66110700AR	Shutter				
83	1	66070493R	Spring				
84	1	66070521R	Shutter				
85	1	66110513R	Deflector				
86	1	66070804R	Support		31/08/2018		
86	1	66070804R	Support	01/09/2018			
87	2	3032018R	Rivet				

## изображение Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
88	1	3045034R	Retainer washer				
89	1	66071060R	Pin				
90	1	66070976	Lever group				
91	1	66070744	Support set				
92	2	66070435R	Bushing				
93	2	3075114R	Screw				
94	1	66110795	Labels kit			Motore Emak; emak engine	
95	1	66070836R	Pin	01/09/2018			
96	1	66070803R	Lock	01/09/2018			
97	1	66070802R	Spring	01/09/2018			
98	2	3045034R	Retainer washer	01/09/2018			


9\*



## изображение Crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	L66150393	Screw				
2	1	L66151522	Cover				
3	1	L66151523	Gasket				
4	1	3055123R	Spark plug				
5	1	L66151524	Crankcase				
6	1	L66150409	Seal ring				
7	3	L66150464	Screw				
8	1	L66151525	Cap				
9	1	L66151570	Gasket set				
10	1	L66150410	Reed valve				
11	1	L66151526	Screw				
12	1	L66151527	Stud				
13	2	L66151528	Stud				
14	1	L66151529	Support				
15	1	L66151530	Brake				
16	1	L66151531	Spring				
17	2	L66151532	Stud				
18	1	L66150453	Screw				
19	1	L66151533	Oil cap assy				
20	2	L66151534	Stud				
21	1	L66151535	Bushing				
22	1	L66151536	Bracket				
23	1	L66150456	Screw				

11\*








## изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	9	L66150817	Bolt				
2	1	L66151537	Couvercle subassment				
3	1	L66150462	Oil seal				
4	1	L66151538	Arbre régulateur				
5	1	L66150035	Rondelle				
6	1	L66150419	Joint				
7	1	L66150353	Goupille				
8	2	L66151539	Pivot				
9	1	L66151540	Regulateur				
10	1	L66150729	Screw				
11	1	L66151570	Gasket set				


2° serie / 2<sup>nd</sup>series

1° serie / 1<sup>st</sup>series




## изображение Shaft + piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151541	Piston ring set				BT5-88-05/23
2	1	L66151571	Piston assy				BT5-88-05/23
3	1	L66150342	Piston pin				
4	2	L66150372	Retainer washer				
5	1	L66151576	Connecting rod				
6	1	L66151577	Crankshaft				
7	1	L66151544	Slide				
8	1	L66152078	Piston ring set			Da utilizzare con pistoni /	BT5-88-05/23
9	1	L66152080	Piston assy			-----, -----	BT5-88-05/23



## изображение Reed valve kit




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66151545	Compensator				
2	1	L66151546	Plate				
3	2	L66150402	Equalizer rod				
4	2	L66151547	Slide				
5	1	L66151548	Camshaft assy				
6	2	L66150398	Spring holder				
7	2	L66150522	Valves spring				
8	2	L66150367	Seal				
9	1	L66150400	Intake valve				
10	1	L66151572	Reed valve kit				



## изображение Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151551	Ignition coil				
2	1	L66150817	Bolt				
3	1	L66151552	Flywheel				
4	1	L66150376	Nut				
5	1	L66151550	Cover				
6	1	L66151549	Starter assy				
7	1	3075226R	Cover			Cover senza etichette / Cover without label	MO_0001_12/1'
8	2	L66150263	Pawl				
9	2	L66150264	Spring				
10	1	L66150262	Spring				
11	1	L66150261	Washer				
12	1	L66152076	Slide				
13	1	L66152077	Screw				
14	1	L66150266	Starter spring				
15	1	L66152075	Pulley				
16	1	L66150270	Starter handle				
17	1	L66150269	Starter rope				
18	1	L66151968	Cover				

3\*






## изображение Carburetor

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151553	Gasket				
2	1	L66151981	Insulator				
3	1	L66151570	Gasket set				
4	1	L66151578	Carburetor				
6	1	L66150731	Shoe				



## изображение Air filter

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151555	Tube				
2	1	L66151556	Filter support				
3	1	L66150715	Air filter				
4	1	L66151557	Filter cover				
5	2	004400959R	Nut				



## изображение Control lever

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151558	Rod				
2	1	L66151559	Throttle rod				
3	1	L66151560	Control lever				
4	1	L66151579	Spring				
5	1	L66151580	Complete lever				
6	1	L66150729	Screw				
7	1	L66150440	Clip				



## изображение Muffler

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151563	Gasket				
2	1	L66151564A	Muffler				
3	1	L66151565	Cover				
4	2	L66150185	Nut				
5	1	L66151566	Control start				
6	2	L66150729	Screw				





## изображение Tank

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151567	Complete tank				
2	1	L66151568	Tank cap				EI5-11/20
3	1	L66150439	Filter				
4	2	L66150456	Screw				
5	1	L66151569	Tube				
6	2	L66150435	Clip				