

LR 48 PK COMFORT PLUS (K605) EURO 5 Lawnmower



Документы

Complete illustrated parts list

Crankcase

Crankcase cover

Shaft + piston

Reed valve kit

Ignition system


Carburetor

Air filter

Control lever

Muffler

Tank




изображение Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060316AR	Brake lever				
2	1	66060384R	Washer				
3	1	66110764A	Deck			Grigio; Grey	
4	1	66030276R	Engine break cable				
5	1	66060421BR	Handlebar				
6	1	66110609A	Kit spring				
7	1	66060231R	Band				
8	2	66070944R	Tightening handle				
9	2	3910015R	Screw				
10	1	66070876R	Grassbag				
11	1	66110753R	Shutter			Rosso; Red	
12	1	66070133R	Support				
13	1	66070522R	Cover				
14	2	3045034R	Retainer washer				
15	2	3024006R	Snap ring				
16	1	66110026R	Deflector axle				
17	2	66070301A	Support set				
18	4	66070248R	Lever				
19	4	66070031R	Lever				
20	1	66030003AR	Blade hub				
21	4	66070030AR	Pin				
22	6	66030012R	Washer				
23	1	66110594R	Mulching blade				
24	4	66070724R	Complete wheel				
25	4	3914012R	Nut				
26	4	66070849R	Wheel cover				
27	4	66070971R	Handle				
28	1	3906150R	Screw				
29	8	3027001R	Washer				
30	1	8202126R	Key				
31	8	66030081R	Bearing				
32	4	3914010R	Nut				
34	1	66070521R	Shutter				
35	1	66070905	Grassbag kit				
38	1	66110828R	Mulching cap				
39	1	66060425R	Handle kit				
40	2	66060317BR	Pin				
41	2	3064037R	Washer				
42	1	66072047R	Frame				
43	1	66070466R	Lock				
45	8	66030012R	Washer				
46	1	66110680	Labels kit				
47	1	66110795	Labels kit			Motore; Engine	
48	1	66070941R	Guard				

изображение Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
49	2	3960137R	Screw				


9*



изображение Crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	L66150393	Screw				
2	1	L66151522	Cover				
3	1	L66151523	Gasket				
4	1	3055123R	Spark plug				
5	1	L66151524	Crankcase				
6	1	L66150409	Seal ring				
7	3	L66150464	Screw				
8	1	L66151525	Cap				
9	1	L66151570	Gasket set				
10	1	L66150410	Reed valve				
11	1	L66151526	Screw				
12	1	L66151527	Stud				
13	2	L66151528	Stud				
14	1	L66151529	Support				
15	1	L66151530	Brake				
16	1	L66151531	Spring				
17	2	L66151532	Stud				
18	1	L66150453	Screw				
19	1	L66151533	Oil cap assy				
20	2	L66151534	Stud				
21	1	L66151535	Bushing				
22	1	L66151536	Bracket				
23	1	L66150456	Screw				

11*






изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	9	L66150817	Bolt				
2	1	L66151537	Couvercle subassment				
3	1	L66150462	Oil seal				
4	1	L66151538	Arbre régulateur				
5	1	L66150035	Rondelle				
6	1	L66150419	Joint				
7	1	L66150353	Goupille				
8	2	L66151539	Pivot				
9	1	L66151540	Regulateur				
10	1	L66150729	Screw				
11	1	L66151570	Gasket set				


2° serie / 2nd series

1° serie / 1st series




изображение Shaft + piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151541	Piston ring set				BT5-88-05/23
2	1	L66151571	Piston assy				BT5-88-05/23
3	1	L66150342	Piston pin				
4	2	L66150372	Retainer washer				
5	1	L66151542	Connecting rod				
6	1	L66151543	Crankshaft				
7	1	L66151544	Slide				
8	1	L66152078	Piston ring set			Da utilizzare con pistoni /	BT5-88-05/23
9	1	L66152080	Piston assy			-----, -----	BT5-88-05/23



изображение Reed valve kit


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66151545	Compensator				
2	1	L66151546	Plate				
3	2	L66150402	Equalizer rod				
4	2	L66151547	Slide				
5	1	L66151548	Camshaft assy				
6	2	L66150398	Spring holder				
7	2	L66150522	Valves spring				
8	2	L66150367	Seal				
9	1	L66150400	Intake valve				
10	1	L66151572	Reed valve kit				



изображение Ignition system


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151551	Ignition coil				
2	1	L66150817	Bolt				
3	1	L66151552	Flywheel				
4	1	L66150376	Nut				
5	1	L66151550	Cover				
6	1	L66151549	Starter assy				
7	1	3075226R	Cover			Cover senza etichette / Cover without label	MO_0001_12/19
8	2	L66150263	Pawl				
9	2	L66150264	Spring				
10	1	L66150262	Spring				
11	1	L66150261	Washer				
12	1	L66152076	Slide				
13	1	L66152077	Screw				
14	1	L66150266	Starter spring				
15	1	L66152075	Pulley				
16	1	L66150270	Starter handle				
17	1	L66150269	Starter rope				
18	1	L66151968	Cover				

3*




изображение Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151553	Gasket				
2	1	L66151981	Insulator				
3	1	L66151570	Gasket set				
4	1	L66151554	Carburetor				
6	1	L66150731	Shoe				




изображение Air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151555	Tube				
2	1	L66151773	Filter support				
3	1	L66150715	Air filter				
4	1	L66151557	Filter cover				
5	2	004400959R	Nut				




изображение Control lever

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151558	Rod				
2	1	L66151559	Throttle rod				
3	1	L66151560	Control lever				
4	1	L66151561	Spring				
5	1	L66151562	Complete lever				
6	1	L66150729	Screw				
7	1	L66150440	Clip				
8	1	L66150237	Spring				



изображение Muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151563	Gasket				
2	1	L66151564A	Muffler				
3	1	L66151565	Cover				
4	2	L66150185	Nut				
5	1	L66151566	Control start				
6	2	L66150729	Screw				



изображение Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151567	Complete tank				
2	1	L66151568	Tank cap				EI5-11/20
3	1	L66150439	Filter				
4	2	L66150456	Screw				
5	1	L66151569	Tube				
6	2	L66150435	Clip				